

## Polyelectrolyte

# INDFLOC<sup>®</sup> 441

## High Efficiency Polyelectrolyte's For Solid-Liquid Separation

### Application

INDFLOC 441 is high efficiency polyelectrolyte, specially designed for solid – liquid separation process. Applications include sedimentation, thickening and clarification of suspension; clarification of aqueous liquor by sedimentation; Dewatering of pulp and sludges for the recovery of liquor or disposal of solids by filtration and centrifugation sludges for the recovery of liquor or disposal.

INDFLOC 441 application is Sedimentation and clarification of Neutral leach in Zinc and Uranium. Metal Hydroxides Filtration of base metal sulphides, oxides and hydroxide concentrate.

### Features

- Marked increase in underflow density.
- Rapid Settling.
- High filtration rate.
- Efficient filter cake washing.
- Effective at low dosages.
- Easy to prepare solution and apply.
- Completely miscible with water.
- Improved filter clarity.
- Increase throughput.

### Product Specifications

Appearance	: White Crystalline powder
Ionic character	: Medium Anionic
pH of 0.1% solution	: 6.0 – 8.0
Stock Solution (0.1%) Viscosity (cps)	: 25 - 75

## Directions for use

INDFLOC 441 may be fed into the vortex of the stirred tank. Eductor may be used for efficient dispersion of polymer. Paddle stirrers operating at 30 to 60 rpm is recommended for dissolution. Use filtered water, free from suspended solids to prepare stock solution of 0.2 to 0.5% of concentration. Prepare feed solution by diluting stock solution about ten times directly or on-line diluting. Water may be heated to 50°C to accelerate the dissolution. Higher temperatures are not recommended. INDFLOC 441 dosage for clarification is normally between 10 to 40 ppm depending on suspended solids.

## Limitations And Handling

Do not store the material in open. Keep the container tightly closed when not in use. These products exhibit very low order of oral toxicity. No special care is required in handling these products.

## Storage

Keep container tightly closed in a cool place.

No warranty, expressed or implied is made, except that the products herein discussed comply with the chemical description. Buyer assumes risks of the use, storage and handling. Ion Exchange (India) Ltd. shall not be liable for any incidental or consequential damages arising directly or indirectly in connection with the purchase, use, storage or handling of this product. The information contained herein is, to the best of our knowledge is true and accurate. However, all recommendations or suggestions are made without guarantee, since the conditions of use are beyond our control. We disclaim any liability incurred in connection with the use of these data or suggestions.

**INDION**, **INDFLOC** and **IONREF** are the registered trademark of Ion Exchange (India) Ltd.



## ION EXCHANGE (INDIA) LTD.

### Corporate Office

Ion House, Dr. E. Moses Road, Mahalaxmi, Mumbai - 400011 | Tel: +91 22 6231 2000 | E-mail: ieil@ionexchange.co.in

### Chemical Division

4<sup>th</sup> Floor, Riviera Apartment, Dwarkapuri Colony, Punjagutta, Hyderabad 500 082 | Tel: +91 40 6831 3101 | E-mail: hydcro@ionexchange.co.in

### International Division

R-14, T.T.C MIDC, Thane - Belapur Road, Rabale, Navi Mumbai - 400 701 | Tel: +91 22 6857 2400 | E-mail: export.sales@ionexchange.co.in

### Regional and Branch Offices

Bengaluru | Bhubaneswar | Chandigarh | Chennai | Delhi  
Hyderabad | Kolkata | Lucknow | Vadodara | Vashi  
Visakhapatnam

### Overseas Offices

Bahrain | Bangladesh | Canada | Indonesia | Kenya  
Malaysia | Oman | Saudi Arabia | Singapore | South Africa  
Sri Lanka | Tanzania | Thailand | UAE | USA

### Manufacturing Units

India - Ankleshwar | Hosur | Patancheru | Rabale | Verna | Wada

Overseas - Bangladesh | Indonesia | Saudi Arabia | UAE

All India Service and Dealer Network

[www.ionexchangeglobal.com](http://www.ionexchangeglobal.com)

